

AD-A213 413

1

MER-0106-FM-8666-86

DEMONSTRATION AND TEST REPORT OF THE WQAU-P
VALIDATION TESTING

Test Performed by:

Foster-Miller, Inc.
350 Second Avenue
Waltham, MA 02254


DTIC
ELECTE
OCT 18 1989
S D

June 1987

CDRL - A013

Contract No. DAAK70-86-C-0106

Distribution Statement



Prepared for

U.S. ARMY BELVOIR RESEARCH, DEVELOPMENT AND
ENGINEERING CENTER
Fort Belvoir, VA 22060-5606

89 10 18 015

Tabular Summary Sheet

WAQU-P/Multiparameter Sensor		Numbers of Total Readings/% Correct						Cumulative Average	
Parameter	Standards Tested	Required Accuracy	1/1	3/8	6/5	7/4	5/3	4/6	
Temperature	320°F, 68°F, 100°F, and 120°F	+20°F	83/94	78/99	78/96	84/96	86/98	84/99	493/97
Extreme Temperature	10°F, 20°F, 140°F, and 160°F	+20°F	40/98	40/75	40/85	40/95	40/60	40/98	240/85
Total Dissolved Solids*	50 and 100 mg/l 500, 1,500, and 3,000 mg/l 30,000 and 50,000 mg/l	+25 mg/l ± 250 mg/l +2,500 mg/l	280/100	280/98	280/93	280/100	280/100	280/100	1,680/98
pH*	4, 7 and 10	+0.5	120/100	120/100	120/100	120/100	120/100	120/100	720/100
Turbidity*	3, 10 and 50 NTU 100 and 150 NTU	+5 NTU +10 NTU	200/99	200/99	200/98	200/89	200/97	200/90	1,200/95
Residual	1, 7.5 and 15 mg/l	+10 mg/l	180/78	180/85	180/93	180/92	180/97	180/88	1,080/89

*Standards tested at temperatures of 32°, 68°, 100°, and 120°F.

**Standards tested at temperatures of 32°, 68°, and 90°F.

TABLE OF CONTENTS:

<u>Section</u>		<u>Page</u>
1	REASON FOR TEST;.....	1
2	DESCRIPTION OF EQUIPMENT TESTED;.....	2
2.1	WQAU-P.....	2
2.2	Multiparameter Sensor.....	2
3	DISPOSITION OF EQUIPMENT;.....	4
4	ABSTRACT OF RESULTS;.....	5
5	TEST APPARATUS;.....	6
6	TEST PROGRAM/PROCEDURES.....	7
6.1	Test Program;.....	7
6.2	Test Data Sheet.....	8
6.3	Test Procedures;.....	8
6.3.1	General.....	8
6.3.2	Temperature (Fluid);.....	12
6.3.3	TDS. Total Dissolved Solids;.....	12
6.3.4	pH.....	12
6.3.5	Turbidity;.....	13
6.3.6	Residual Chlorine;.....	13
6.3.7	Temperature (Air).....	14
6.4	Acceptance Criteria.....	14

TABLE OF CONTENTS (Continued)

<u>Section</u>		<u>Page</u>
7	TEST RESULTS.....	21
	7.1 Temperature.....	22
	7.2 Extreme Air Temperatures.....	23
	7.3 Total Dissolved Solids.....	23
	7.4 pH.....	24
	7.5 Turbidity.....	24
	7.6 Residual Chlorine.....	24
8	RAW TEST DATA.....	27

LIST OF TABLES

<u>Table</u>		<u>Page</u>
1	Parametric Test Matrix.....	13
2	Parametric Field Calibration Requirements.....	18
3	WQAU-P Accuracy Requirements.....	20
4	Cumulative Test Results.....	21
5	Test Results for Individual WQAU-Ps.....	22
6	Breakdown of Residual Chlorine Errors.....	26

1. REASON FOR TEST

To establish/validate the measurement capabilities of the Water Quality Analysis Unit-Purification (WQAU-P) that has been modified to accept the newly developed Foster-Miller multiparameter sensor.

2. DESCRIPTION OF EQUIPMENT TESTED

2.1 WQAU-P

The WQAU-P is a rugged, simple-to-operate, accurate and highly reliable water quality analysis unit that is capable of analyzing the temperature, total dissolved solids, pH, turbidity and residual chlorine of:

- Raw water feed to a reverse osmosis purification system
- Product water from a reverse osmosis purification system
- Raw water in situ (lakes, ponds, rivers, oceans).

The WQAU-P combines five water quality monitoring sensors with a state-of-the-art microprocessor to form a self-calibrating and easy to operate water monitoring instrument. The WQAU-P utilizes only one wet standard that is generated from a hermetically sealed packet of buffer powder (pH of 7). The logistic support problems of maintaining a fresh supply of perishable chemicals has been eliminated. Trained personnel can typically obtain a complete set of readings in less than 5 min.

The WQAU-P tested in this program was a modified version of the WQAU-P developed under contract DAAK70-85-C-0022.

2.2 Multiparameter Sensor

The Foster-Miller multiparameter sensor contains four water quality monitoring sensors (temperature, pH, conductivity (TDS) and turbidity). The temperature and conductivity sensors have pin socket connectors at their electrical end and are keyed

into the multiparameter assembly for alignment with the mating internal pins. The pH sensor is a threaded coaxial connector that is backed with an o-ring to provide additional water seepage protection. Each of these sensors is secured/sealed into the multiparameter assembly by a spanner nut that is backed with a rubber seal.

3. DISPOSITION OF EQUIPMENT

Six WQAU-Ps plus eight multiparameter sensors have been delivered to Fort Belvoir or a Fort Belvoir representative. Two multiparameter sensors remain at Foster-Miller to support Foster-Miller field service activities. These last two multiparameter sensors will be delivered to Fort Belvoir at the completion of Phase II testing (August 1987).

4. ABSTRACT OF RESULTS

Six WQAU-Ps with individual multiparameter sensors were subjected to an extended matrix of tests. More than 5,400 individual measurements were taken/recorded. Over 95 percent of the readings fell within the accuracy requirements for the parametric readings. The multiparameter sensor (temperature, TDS, pH and turbidity) provided over a 97 percent accuracy rate. Residual chlorine accuracy was 89 percent.

Over 55 percent of the TDS errors occurred when measuring salt concentrations of 50,000 mg/l (upper level of measurement). Turbidity errors were evenly distributed over all ranges. Approximately 60 percent of the residual chlorine errors occurred at the upper limit of 15 mg/l. Approximately 75 percent of the temperatures errors occurred below 40°F when measuring fluids between 32°F and 120°F. At extreme temperatures (10°F to 20°F and 140°F to 160°F), 95 percent of the errors occurred at the high range.

5. TEST APPARATUS

The following test equipment was used to perform WQAU-P validation tests.

<u>Equipment/Chemicals</u>	<u>Manufacturer</u>
Turbidity Meter, Model DRT-100D 0 to 10, 0 to 100, and 0 to 1,000 NTU, ± 1 percent FS	HF Instruments, Inc. VWR Scientific Boston, MA
Santorious Balance Model 2474 160 gm maximum, 0.001 gm accuracy calibrated 5/86	VWR Scientific Boston, MA
Immersion Heater/Circulator Model 13276-456, 110 Vac	VWR Scientific Boston, MA
Polyethylene Tanks, 12 x 12 x 18 in.	Teracom Corp. Waltham, MA
NBS Certified Thermometer Model 15-041A, Purchased Jan 1987 -10 to 51°C, $\pm 0.1^\circ\text{C}$	Fischer Scientific Medford, MA
Buffer Solutions pH 4 - SO-B-101 pH 7 - SO-B-107 pH 10 - SO-B-115	Fischer Scientific Medford, MA
Biological Grade NaCl Product S-671	Fischer Scientific Medford, MA
Formazin Stock Solution Product 15-393-2, 4,000 NTU	Fischer Scientific Medford, MA
DPD50 Free Available Chlorine R501 FAS Titrant R502 DPD Powder Buffer	Delta Analytical, Inc. Hauppauge, NY

6. TEST PROGRAM/PROCEDURES

6.1 Test Program

Table 1 details the test matrix that was followed when collecting process/validation data on the Phase III WQAU-Ps/multiparameter sensors. This table lists the measurement levels, fluid operating ranges (temperature and pH), number of measurements, number of measurements per sample and number of total measurements for each WQAU-P/multiparameter sensor.

Table 1. Parametric Test Matrix

Parameter	Measurement Level	Fluid Operating Range	Measurements	Measurements per Sample	Total Measurements
pH	4, 7, 10 pH units	36°F, 68°F, 100°F, 120°F	12	10	120
TDS	50, 100, 500, 1,500, 3,000, 30,000, 50,000 mg/l	36°F, 68°F, 100°F, 120°F	28	10	280
Turbidity	3, 10, 50, 100, 150 NTU	36°F, 68°F, 100°F, 120°F	20	10	200
Residual Chlorine	1, 7, 15	36°F, 68°F, 90°F and 5.5, 7.5 pH units	18	10	180
Temperature (Air)	10°F, 20°F, 140°F, 160°F	N/A	4	10	40

6.2 Test Data Sheet

A sample test data sheet is illustrated in Figure 1. Individualized data sheets were used for each monitored parameter and for each WQAU-P/multiparameter sensor tested. Multiple data sheets were used when one sheet was insufficient.

The column on the left was used to enter the value of the standard that was monitored. The next column was used to record the fluid temperature as measured by both the WQAU-P and the certified thermometer (actual). The third column was used to record the fluid's pH. This column was only used during residual chlorine measurements. The remaining 10 columns were used for recording the 10 individual measurements of the monitored standard.

6.3 Test Procedures

All testing was conducted with the WQAU-Ps connected to 110 Vac. The following test procedures describe how each of the WQAU-P parameters were tested/validated.

6.3.1 General

For any given parameter a sufficient quantity of appropriate test standards was prepared and divided into four test containers (fluid chambers). Each test container was placed in one of the four constant temperature baths (36°F, 60°F, 100°F and 120°F). The pH evaluation, for example, had three standards (pH of 4, 7 and 10) in each of the four constant temperature baths. The pH of each standard was then measured at a single temperature. When the 30 readings (10 each for each pH standard) at a single temperature was completed, testing continued at the next temperature level. This cycle continued until all standards were measured at each of the four temperatures. For pH this resulted in a total of

WQAU-P TEST DATA SHEET

Monitored Parameter _____ WQAU-P Unit _____
Sheet _____ of _____

[illegible]

Figure 1. WQAU-P Test Data Sheet

120 measurements per WQAU-P. A sample WQAU-P Test Data Sheet for pH is illustrated in Figure 2. This was the general test sequence that was used for all WQAU-P parameters except residual chlorine and air temperature.

Prior to collecting parametric data with the WQAU-P, a field calibration sequence was performed on the pertinent WQAU-P parameters. These field calibration procedures followed the field calibration procedures described in the Phase II WQAU-P Operation/Maintenance Manual (Contract DAAK70-86-C-0022). Table 2 details which parameters were field calibrated before obtaining a specific parametric measurement (a set of 10 readings).

To obtain a parametric measurement with the WQAU-P, the operator must press the "Press to Read" button. Since some sensors take time to stabilize (reach thermal equilibrium), the operator should alternately press and release the "Press to Read" button until the WQAU-P reading (digital display) has stabilized at a fairly constant value. For example, if a room temperature (70°F) thermistor is immersed in cold water (40°F), the first few readings displayed by the WQAU-P (one reading each time the "Press to Read" button is pressed) should steadily decrease. The true temperature is reached when successive readings remain constant. This procedure was followed for all measurements when required.

Specific procedures for each parameter are discussed in the following subsections.

WQAU-P TEST DATA SHEET

Monitored Parameter pH WQAU-P Unit 001
 Sheet 1 of 1

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
2	32.4 / 32°F	—	2.1	2.2	1.9	etc...
7	32.6 / 32	—										
12	32.2 / 32	—										
	/											
2	75.0 / 75°F	—										
7	75.2 / 75	—										
12	75.1 / 75	—										
	/											
2	100.1 / 100°F	—										
7	100.4 / 100	—										
12	101.0 / 100	—										
	/											
2	117.3 / 120°F	—										
7	117.4 / 120	—										
12	117.9 / 120	—						12.1 12.2
	/											
	/											
	/											
	/											
	/											

* ONLY USED FOR RESIDUAL CHLORINE MEASUREMENTS

Figure 2. Completed WQAU-P Test Data Sheet for pH

Table 2. Parametric Field Calibration Requirements

Monitored Parameter	Parameter(s) Requiring Field Calibration
Temperature (Fluid and Air)	None
TDS	TDS
pH	pH
Turbidity	Turbidity
Residual Chlorine	Residual Chlorine and pH

6.3.2 Temperature (Fluid)

The temperature of each fluid standard was measured using both the WQAU-P and the certified thermometer prior to obtaining the 10 parametric measurements. Both of the measured fluid temperatures were documented in the temperature column of the Test Data Sheet.

6.3.3 TDS

TDS measurements were obtained using fluid standards that have been prepared by dissolving laboratory grade NaCl in deionized/demineralized water. For each condition (salt concentration and temperature) the temperature of the standard was measured with the WQAU-P prior to obtaining TDS readings. The multiparameter sensor was flushed and dried prior to changing standards.

6.3.4 pH

Certified pH buffers were used as standards during this phase of the test program. For each condition (pH value and temperature) the temperature of the standard was measured with

the WQAU-P prior to obtaining pH readings. The multiparameter sensor was flushed in deionized/demineralized water prior to changing standards.

6.3.5 Turbidity

Turbidity measurements were obtained using Formazin as the turbidity standard. The NTU value of the turbidity standards was verified using a recently calibrated HF Instrument (Model DRT-100D) laboratory turbidity monitor. Verification of an individual turbidity standard was performed before a sequence of measurements (set of 10 readings) initiated. The multiparameter sensor was flushed with deionized/demineralized water and dried prior to changing standards.

6.3.6 Residual Chlorine

Determination of the chlorine standard's chlorine concentration was achieved using a DPD-50 Residual Chlorine Test Kit. A DPD buffer/indicator was used to give the chlorinated water a rose-colored appearance. A RAF titrant was used to neutralize the color. Each drop of titrant was equivalent to 0.2 mg/l.

For each condition (chlorine concentration, pH and temperature), the pH and temperature of the chlorine standard were measured by the WQAU-P prior to obtaining a chlorine measurement.

The WQAU-P chlorine sensor reacts with chlorine during the measurement process. This reaction results in the depletion of chlorine (i.e., drop in chlorine concentration). Due to this reaction, a large volume (4 gal) of standard was utilized to minimize changes in the chlorine concentration.

6.3.7 Temperature (Air)

Extreme air temperature measurements were made using a dry ice chamber for 10° and 20°F, and a drying oven for 140° and 160°F.

6.4 Acceptance Criteria

The accuracy requirements for each parameter are detailed in Table 3.

Table 3. WQAU-P Accuracy Requirements

Parameter	Range	Accuracy
Temperature (Fluid)	32° to 120°F	±2.0°F
TDS	0 to 500 mg/l	±25 mg/l
	500 to 5,000 mg/l	±250 mg/l
	5,000 to 50,000 mg/l	±2,500 mg/l
pH	2 to 12 pH units	±0.5 pH units
Turbidity	0 to 50 NTU	±5 NTU
	50 to 150 NTU	±10 NTU
Residual Chlorine	0 to 15 mg/l	±1.0 mg/l
Temperature (Air)	0° to 160°F	±2.0°F

7. TEST RESULTS

More than 5,400 individual measurements were taken/recorded with the Phase III WQAU-P/multiparameter sensors. Over 95 percent of the readings fell within the accuracy requirements for the parametric measurements. The multiparameter sensor provided over a 97 percent accuracy rate. Residual chlorine was less impressive, logging an 89 percent accuracy rate.

The cumulative percentage of correct readings for each parameter is listed in Table 4.

On an individual WQAU-P basis, the percentage of correct parametric measurements ranged as follows:

- Temperature (fluid) - 94 to 99 percent
- Extreme temperature (air) - 60 to 98 percent
- pH - 100 percent (no failures)
- Turbidity - 89 to 99 percent
- Residual chlorine - 78 to 97 percent.

Individual WQAU-P results are summarized in Table 5.

Table 4. Cumulative Test Results

Parameter	Total Number of Tests	Percent Correct Readings
Temperature (Fluid)	493	97
Extreme Temperature (Air)	240	85
Total Dissolved Solids	1,680	98
pH	720	100
Turbidity	1,200	95
Residual Chlorine	1,080	89

Table 5. Test Results for Individual WQAU-Ps

WQAU-P/Multiparameter Sensor	1/1	3/8	6/5	7/4	5/3	4/6
Parameter	Percent Correct Readings					
Temperature (Fluid)	94	99	96	96	98	99
Extreme Temperature (Air)	98	75	85	95	60	98
Total Dissolved Solids	100	98	98	93	100	100
pH	100	100	100	100	100	100
Turbidity	99	99	98	89	97	90
Residual Chlorine	78	85	93	92	97	88

The remaining discussion focuses on the errors (deviation from standard that exceeds acceptance criteria) that were encountered, the corrective measures that were taken and the accuracy improvements that could be obtained by relaxing the parametric constraints at extreme ranges (i.e., TDS concentrations at 50,000 mg/l).

7.1 Temperature

Most of the temperature errors (75 percent) occurred when measuring fluids that were less than 40°F. The bulk of these errors occurred during testing of the first three units (WQAU-Ps 1, 3, and 6). During the prevalidation testing of WQAU-Ps 7 and 5, the source of low temperature errors was quantitatively established.

As designed the WQAU-P would receive a thermistor input that was processed into an analog millivolt signal that was equivalent to degrees Centigrade (i.e., 20°C would be input as 20 mV). At low fluid temperatures, those reaching 32°F (0°C), (i.e., equivalent to a 0-mV input), the analog to

digital converter (A/D) would occasionally shift by 1 to 2 mV. This source for signal deviation generated an error of 1.8° to 3.5°F , easily exceeding the WQAU-P accuracy requirements.

The temperature processing circuit was modified by amplifying the analog signal by a factor of 10 (i.e., a 20°C input would be equivalent to a 200-mV signal). A 1- to 2-mV shift at 32°F (0°C) now generated only a 0.18° to 0.36°F error. After this change was made, temperature errors were reduced to infrequent random (range) variations.

7.2 Extreme Air Temperatures

Ninety-five percent of the extreme air temperature errors occurred at the elevated temperatures (140° and 160°F). Correction of the temperature measuring flaw described in subsection 7.1 had no influence on these temperature ranges. Both ranges, 10° to 20°F (-12° to -6.7°C) and 140° to 160°F (60° to 71°C) are well beyond the 0-mV input that upsets the A/D converter output.

If the accuracy for extreme air temperature was increased to 4°F , the total average error would be only 3 percent, a 97 percent accuracy rate.

7.3 Total Dissolved Solids

TDS errors were limited to the high and low measurement ranges (42 and 58 percent, respectively). Low range errors varied from 27 to 40 mg/l, averaging 33 mg/l. High range errors varied from 2,520 to 2,800 mg/l and occurred when measuring the 50,000-mg/l standard.

7.4 pH

Although there were no recorded errors, a drop in the measured pH value occurred at the lower test temperature (36° to 40°F). Figure 3 graphically illustrates this relationship for all pH buffers tested. Above 60° to 70°F, the measured pH values remained fairly constant, drifting upward only 0.1 to 0.2 pH units. Below this temperature range, pH values dropped by 0.3 to 0.5 pH units as the test standard temperature approached 32°F.

7.5 Turbidity

Turbidity errors, while in general being random relative to NTU value, were most prominent at the two upper temperatures (100° and 120°F). Ninety-eight percent of all turbidity errors occurred when measuring standards at these temperatures (38 and 60 percent, respectively). At the upper turbidity range (50 to 150 NTU, ± 10 NTU), the turbidity errors varied from 11 to 26 NTU, averaging just under 15 NTU. At the lower turbidity range (0 to 50 NTU, ± 5 NTU), the measurement errors varied from 6 to 12 NTU, with an average of 7.7 NTU.

7.6 Residual Chlorine

Table 6 illustrates how the frequency of residual chlorine errors increased as the chlorine concentration of the test standard increased. Ninety percent of the chlorine errors occurred when measuring chlorine concentrations at or above 7.0 mg/l. The average error for the high range (15 mg/l) was 1.74 mg/l. The average error for the mid range (7 mg/l) was 1.4 mg/l. If the accuracy constraint for chlorine was relaxed to ± 1.5 mg/L at the upper two ranges, the WQAU-P's chlorine accuracy would increase to 96 percent.




Figure 3. Influence of Sample Temperature on pH

Table 6. Breakdown of Residual Chlorine Errors

Standard (mg/l)	Percentage of Errors
1	10
7	31
15	59

All supporting test data (raw data) ha been included in the following section.

8. RAW TEST DATA

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 2

TDS

WQAU-P Unit 1

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
50 mg/L	66.2/67.4		49	49	50	50	50	50	50	50	50	59
100	68/67.8		92	94	92	92	92	92	92	92	92	93
	/											
50	42.8/42.8		40	40	40	40	40	41	40	40	40	40
50	98.2/		45	45	44	44	43	42*	44	44	44	44
50	118/		46	46	44	44*	43	43	43	43	42	42
	/											
100	37.4/		98	98	98	99	99	102*	103	103	107	109
100	48.6/		105	104	106	101	100	99*	99	99	97	97
100	117.5/		94	94	94	92	92	90*	91	91	90	90
	/											
500	118.4/		525	524	523	523	519	516*	529	526	524	524
500	167.6/		494	496	495	495	494	493	491*	498	497	496
500	75/		519	518*	530	531	532	534	535	536	536	537
500	37.7/		520	524*	530	531	542	570*	566	570	571	573
	/											
1500	37.4/		1545	1541	1538	1536	1536	1536	1536	1536	1536	1545
1500	65.3/		1491	1493	1497	1500	1504	1504	1504	1504	1504	1501
1500	100/		1442	1437	1429	1425	1416	1408	1440	1431	1418	1405
1500	114.8		1446	1444	1436	1429	1411*	1408	1408	1386*	1383	1363

932/94.9
113/112.3

39.2/40.0

95/94.3

113/111.7

113/111.7

104/104

75.2/74.0

41.0/42.1

39.4/41.4

64.3/65

95.0/91.6

109.4/111.2

COMMENTS / OBSERVATIONS : * New temperature taken by WQAU-P.

** Temperatures taken at End

DATE : 4/4/87

SIGNATURE : *[Signature]*

Monitored Parameter pH WQAU-P Unit 1
Sheet of

COMMENTS / OBSERVATIONS :

SIGNATURE : 

WQAU-P TEST DATA SHEET

Monitored Parameter TDS WQAU-P Unit 1
Sheet 2 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
3000mg/L	120.1		2914	2884*	2931	2909	2870	2848*	2857	2826	2802*	2811	114.2/113.7
	105.0		2962	2958	2945	2937	2924	2916*	2960	2953	2947	2940	102.2/103.0
	73.3		3074	3066	3056	3052	3050	3050	3050	3050	3050	3056	73.3/76.0
	39.2		3224	3211	3191	3180	3162	3158	3153	3153	3153	3150	34.2/41.6
	/												
30,000	39.4		31555	31609	31918	31826*	31064	31064	31169	31169	31169	31275	42.4/43.4
	64.3		30118	30268	30343	30419	30867*	30867	30867	30867	30867	30867	64.3/65.1
	101.2		28915	28805	28815	28815	28765	28765	28765	28715	28665	28510	97.4/90.0
	114.4		28513	28513	28513	28513	28469	28429*	28705	28662	28610	28570	114.2/113.5
	/												
50,000	42.8		50211	50313	50416	50416	50518	50569	50620	50722	50722	50825	44.6/47.9
	66.2		47763	47824	47801	47801	47801	47801	47801	47801	47801	47806	66.2/67.1
	105.8		42223	42134	42134	42065	42065	42036	41987*	42622	42572	42522	102.2/102.0
	114.8		41433	41367	41357	41261	41261	41261	41210	41171	41171	41125	112/111.4
	/												
50,000	6.8		49500	49600	49503	49503	49503	49503	49600	49600	49600	49600	65/67.1
	39.2		50522	50522	50522	50575	50575	50575	50575	50575	50575	50622	40.1/40.5
	99		47396	47386	47114	47174	47234	47211	47211	47556	47556	47444	98/97.6
	110.4		44446	44346	44346	44397	44397	44346	44346	44323	44249	44250	91.0/92.7
	100.4/99.6		50624	50579	50579	50574	50521	50521	50521	50521	50463	50463	114.2/110.5

COMMENTS / OBSERVATIONS : 117.5/ 49117 49958 48798 48634 48480 49469 49250 49086 48977 48922

* Error in TDS program at high (+40,000mg/L) conductivity corrected. Validation testing repeated.

TDS @ 50,000 drop in accuracy above 100°F

** 2nd change to software high end TDS.
4/9/87

DATE : 4/4/87

SIGNATURE : J.S. Rubin

WQAU-P TEST DATA SHEET

Monitored Parameter Turbidity WQAU-P Unit 1
 Sheet 1 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
150 NTU	68'		148	152	144	146	146	146	149	149	149	148
102	65'		104	101	102	101	103	106	110	108	108	110
52	64.3'		52	53	52	53	54	54	54	54	53	52
11.5	64.3'		11	11	9	10	9	12	11	12	11	11
3.7	64.3'		1	2	2	2	5	3	3	2	2	2
air bubbles												
37	37.4'		2	2	2	3	2	2	2	3	2	2
9.0	37.4'		7	8	10	9	9	8	8	7	8	9
52.0	34.2'		52	53	52	50	54	53	53	52	53	56
97.0	34.2'		97	98	97	99	98	101	100	98	99	98
147	34.2'		147	148	148	147	148	148	147	146	147	146
146	103'		143	143	142	142	142	140	145	143	146	148
98.5	104'		100	101	100	97	98	105	107	98	102	104
51	104'		46	47	47	46	52	51	50	52	55	54
10.6	105.8'		10	9	8	8	12	10	11	11	11	11
3.7	105.8'		4	4	0	1	2	7	7	6	6	7

After Temp
 WQAU-P
 Actual
 68/68.9
 65/66.5
 65.3/66.2
 66/66.2
 66.5/67.9

34.2/41
 41/43
 34.2/41
 37.6/39.7
 39.2/39.2
 93.2/92.7
 96.7/96.2
 98.6/98.2
 100.4/100.4
 100.4/99.9

COMMENTS / OBSERVATIONS :

DATE : 4/6/87

SIGNATURE : JG Plim

Monitored Parameter Turbidity WQAU-P Unit: 1
Sheet 2 of 2

[illegible]

DATE : 4/6/87

SIGNATURE : *SS Robin*

WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine WQAU-P Unit 1
Sheet 1 of 1

[illegible]

COMMENTS / OBSERVATIONS :


DATE :

SIGNATURE :

Monitored Parameter Air Temp WQAU-P Unit 1
Sheet 1 of 1

[illegible]

DATE : 4/6/87

SIGNATURE : 


WQAU-P TEST DATA SHEET

Monitored Parameter pH WQAU-P Unit 3
 Sheet 1 of 1

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
7.0	68.1		7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	68.1/69
4.0	71.6		4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	71.6/71.8
10.0	71.6		10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	69.8/70.3
	/												
10.0	37.4		9.8	9.8	9.7	9.7	9.7	9.7	9.6	9.6	9.6	9.6	35.6/36.5
7.0	39.2		6.5	6.5	6.5	6.5	6.5	6.5	6.5	6.5	6.5	6.5	42.8/42.8
4.0	39.4		3.6	3.5	3.5	3.5	3.6	3.6	3.5	3.5	3.5	3.5	37.4/39.2
	/												
4.0	93.2		4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.0	4.1	4.0	89.6/90.5
7.0	96.7		7.1	7.1	7.1	7.1	7.1	7.0	7.0	7.0	7.0	7.0	95.0/95.0
10.0	96.7		10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	96.7/96.6
	/												
10.0	113		10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	111.2/111.0
7.0	111		7.1	7.1	7.1	7.1	7.1	7.1	7.1	7.1	7.1	7.1	109.4/109.0
4.0	111.2		4.2	4.2	4.2	4.1	4.1	4.1	4.1	4.1	4.1	4.1	109.1/110.3
	/												
	/												
	/												
	/												
	/												
	/												

COMMENTS / OBSERVATIONS :

DATE : 4/8/87

SIGNATURE : 

WQAU-P TEST DATA SHEET

Monitored Parameter TOS WQAU-P Unit 3
 Sheet 1 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
50	39.2'		53	53	53	54	54	54	54	54	55	55	39.2/41.2
	69.8'		47	47	49	48	49	49	50	49	49	50	71.0/73.1
	98.6'		43	43	43	43	43	43	43	43	42	42	93.2/94.4
✓	124'		54	54	58	54	54	53	54	54	54	52	115/114.7
100	37.4/35.6		98	99	98	100	99	99	99	99	100	100	37.4
	69.8'		118	116	116	118	118	118	118	118	118	118	69.8/71.6
	105.8'		84	86	86	85*	85	85	85	85	84	84	102.2/103.1
✓	118.6'		84	84	83	84	82*	84	84	83	83	82	117.4/118.0
500	37.4/36.8		486	486	493	495	496	496	497	497	497	496	37.2
	66.2'		465	466	466	466	466	466	466	467	467	467	68/69.8
	104.0'		453	450	448*	453	453	450	450	448*	461	458	102.2/102.4
✓	117.6'		460	452	450*	458	452	440	438*	457	450	455	115/116.1
1500	66.2/65.8		1476	1475	1488	1480	1490	1498	1501	1502	1507	1513	68/69.5
	37.4/35.6		1471	1443	1434*	1499	1499	1499	1503	1505	1506	1510	37.4
	103.2'		1523	1523	1523	1521	1523	1515	1517	1515	1511	1524	101/100.2
✓	118.4'		1513	1513	1515	1509	1501*	1534	1530	1527	1520	1518	117.4/116.5

COMMENTS / OBSERVATIONS :

DATE : 4/8/87

SIGNATURE :

[Handwritten Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 2 of 2

TPS

WQAU-P Unit

3


Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
3000	35.6/36.0		3060	3060	3060	3060	3060	3060	3060	3060	3060	3060
↓	68 °		3107	3107	3114	3120	3133 [†]	3139	3135	3139	3139	3146
↓	103.1 °		3122	3132	3132	3182	3178 [†]	3219	3206	3215	3177	3119
↓	120.2 °		3135	3127	3116	3102	3097 [†]	3154	3142	3140 [†]	3177	3160
30000	66.2 °		3063	3060	30652	30652	30762	30762	30800	30800	30800	30800
↓	35.6/36.2		29911	29811	29811	29821	29821	29821	29821	29821	29821	29821
↓	104 °		28762	28762	28855	28855	28855	28855	28855	28855	28855	28855
↓	120.2 °		28794	28729	28767	28796	28752	28763	28764	28771	28726	28742
50000	66.2/68.2		48384	48347	48347	48347	48397	48347	48347	48347	48347	48347
↓	37.4/38.1		49434	49325	49325	49325	49216	49217	49217	49217	49217	49217
↓	104 °		48092	47927	48158	48124	48009	47825	48648	48597	48441	48922
↓	120.2 °		47607	47734	47355	47323	47441	47384	47336	47520	47443	47412

COMMENTS / OBSERVATIONS :

DATE :

4/8/07

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter Turbidity WQAU-P Unit 3
 Sheet 1 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
150	68.1		151	151	151	151	151	153	151	151	151	151	68/68.5
103 103	68.1		108	108	103	104	104	109	106	107	104	109	68/69
53	67.1		54	57	54	59	56	55	56	58	57	57	67/68
10.6	66.2		13	12	13	16	15	10	11	12	11	12	66.2/68
3.6	68.1		4	4	5	6	5	4	3	4	4	3	
	1												
155.8	37.4		147	150	153	153	153	153	153	153	153	153	37.4/38.5
105.0	35.6		102	104	107	106	107	107	107	107	105	107	37.1/38.1
52.4	37.4		54	56	54	56	56	54	56	56	56	56	38.2/38.5
11.4	37.4		10	10	11	12	11	11	11	11	11	11	37.1/38.1
4.1	37.4		8	5	5	5	6	6	5	5	6	5	37.2/38.7
	1												
148	100.4		144	142	143	142	144	143	143	142	143	143	93.4/93.6
100.4	102.1		98	99	98	100	95	100	98	106	105	99	89/90.1
51	97.1		49	51	50	51	52	52	51	51	51	51	97.7/97.9
11	103.1		10	11	11	12	8	10	9	9	8	10	98.3/99.1
2.7	99.1		6	6	7	6	2	3	4	5	4	2	100.7/100.7
	1												
	1												
	1												

COMMENTS / OBSERVATIONS :

DATE :

4/9/87

SIGNATURE :

J. A. H. [Signature]

Monitored Parameter Turbidity WQAU-P Unit 3
Sheet 2 of 2

[illegible]

DATE : 4/9/87

SIGNATURE : 

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet _____ of _____

Turbidity

WQAU-P Unit

86

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
152	68.2/67.8		144	148	148	160	155	157	163	157	158	156
101	68.4/67.6		94	94	98	97	96*	103	102	104	96	100
52	67.3/67.6		50	50	51	50	48	47*	49	50	51	50
11.4	68.0/67.8		12	4	7	8	7*	10	4	12	12	11
4.1	68.1/67.6		3	2	2	8	6	8	4	4	3	1
155	36.8/37.0		160	154	154	158	161	161	157	156	154	155
104	37.4/38.0		101	101	102	102	100	94	97*	99	94	97
54	37.6/37.0		56	52	53	54	54	55	53	51	51	44
12.2	37.6/37.6		10	11	11	9	6*	8	7	4	13	12
4.0	37.7/39.2		3	2	2	1	3	4	2	5	4	4
144	92.4/96.8		141	141	149	144	156	144	148	148	150	151
100	98.2/92.8		103	108	111	109	109	107	106	94	98	103
51	98.8/92.8		53	52	52	53	51	49	50	50	51	55
10.2	98.0/92.8		14	14	15	13	12	9	12	11	14	8
3.8	96.1/96.0		1	4	1	2	6	1	7	3	6	4
151	118.1/117.8		161	154	158	163	160	158	157	156*	164	157
107	117.3/117.6		110	111	110	108	109	107	114	116	111	112
54	118.2/118.0		56	58	56	57	44	61	54	54	52	52
10.4	118.4/118.0		10	10	4	10	12	10	8	6	8	11
3.2	114.0/117.8		1	1	3	1	2	4	6	4	3	2

COMMENTS / OBSERVATIONS :

DATE : 4/4/07

SIGNATURE : [Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet ____ of ____

pH

WQAU-P Unit

g/l

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
4	68.2/67.4		4.0	4.0	4.0	4.0	4.1	4.1	4.2	4.0	4.0	4.0
7	68.4/67.6		7.0	7.0	7.0	7.1	7.1	7.1	7.1	7.1	7.1	7.1
10	66.6/67.0		10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1	10.1
	/											
4	38.6/38.4		3.7	3.7	3.6	3.6	3.6	3.6	3.6	3.6	3.6	3.6
7	34.0/38.6		6.7	6.7	6.8	6.7	6.7	6.7	6.7	6.8	6.8	6.8
10	38.8/38.6		9.7	9.7	9.7	9.8	9.8	9.8	9.8	9.8	9.8	9.8
	/											
4	92.2/92.4		4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1
7	96.8/92.0		7.1	7.1	7.1	7.1	7.2	7.2	7.2	7.2	7.2	7.2
10	92.0/92.2		10.1	10.1	10.2	10.2	10.2	10.2	10.2	10.2	10.2	10.2
	/											
4	116.4/116.2		4.1	4.1	4.1	4.1	4.1	4.1	4.2	4.2	4.2	4.2
7	116.4/116.0		7.2	7.2	7.2	7.2	7.2	7.2	7.2	7.2	7.2	7.2
10	116.0/116.4		10.2	10.3	10.3	10.3	10.2	10.2	10.2	10.2	10.2	10.2
	/											
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

DATE :

4/4/87

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 2

TDS

WQAU-P Unit

36

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
50	67.2/67.0		53	54	54	56	54	54	54	56	56	56
100	67.4/67.2		96	96	97	96	95	94	95	96	95	95
500	67.4/67.2		402	400	402	403	404	405	405	405	404	400
1500	67.2/67.2		1402	1400	1398	1402	1400	1400	1400	1400	1400	1402
3000	67.4/67.2		2896	2880	2880	2840	2844	2816	2806	2844	2800	2800
30,000	67.4/67.2		29212	29205	29205	29264	29260	29258	29260	29260	29277	29270
50,000	67.0/67.2	2	48242	48255	47200	47600	47200	47692	47692	48110	48110	48009
50	38.2/38.0		51	51	52	52	55	54	54	54	52	52
100	38.2/36.0		100	98	96	96	96	98	97	94	97	97
500	38.4/36.2		474	477	483	483	483	488	479	476	480	482
1500	38.2/38.2		1401	1398	1396	1404	1406	1400	1401	1401	1390	1394
3000	38.0/38.0		2910	2902	2917	2925	2917	2900	2886	2888	2901	2901
30000	37.8/37.6		29425	29401	29401	27470	29111	28444	29331	29340	29411	29404
50,000	37.8/37.6		49699	49751	49751	50018	50004	50041	49942	49405	49510	49455

COMMENTS / OBSERVATIONS :

DATE :

4/9/07

SIGNATURE

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter TDS WQAU-P Unit mg/L
 Sheet 2 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
50	98.8/99.0		47	48	48	48	51	50	48	48	50	52
100	98.6/99.0		94	97	96	96	96	97	91	98	93	94
500	99.0/99.2		498	490	491	491	498	491	491	490	482	479
1500	99.2/99.2		1424	1420	1424	1420	1434	1438	1460	1451	1451	1451
3000	99.0/99.2		2924	2904	2917	2927	2901	2881	2901	2905	2941	2924
20,000	98.4/98.8		30,111	30,019	30,044	30,111	30,201	30,020	29,940	29,940	29,867	29,821
50,000	98.6/98.8		51,189	51,189	52,013	51,976	51,976	50,331	50,220	50,215	50,044	51,181
	/											
	/											
50	118.8/117.8		46	46	45	45	45	45	45	43	41	45
100	118.2/117.8		90	91	90	91	91	91	91	92	91	91
500	119.1/119.0		484	482	481	484	484	484	484	479	484	484
1500	120.0/120.2		1406	1406	1401	1401	1401	1399	1398	1399	1399	1399
3000	120.0/120.4		2889	2889	2882	2945	2913	2913	2898	2889	2881	2881
30,000	148.2/118.0		29846	29660	29660	29176	29411	29411	29612	29660	29660	29752
50,000	119.8/117.5	1	52,247	52,184	52,189	52,231	52,491	52,164	52,164	52,164	52,164	52,164
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

DATE : 4/2/87

SIGNATURE : *[Signature]*

WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine WQAU-P Unit mg/l
 Sheet 1 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
17.8	67.4/67.0	7.4	16.9	17.2	17.4	17.4	17.2	17.2	17.0	16.7	16.7	16.8
8.1	68.0/68.0	7.3	7.8	7.8	7.7	7.6	7.5	7.6	7.2	7.2	7.1	7.0
1.6	66.8/66.6	7.2	1.2	1.2	1.3	1.2	1.3	1.3	1.3	1.2	1.2	1.1
	/											
14.6	68.0/68.2	5.6	14.1	14.1	14.0	13.7	13.9	13.5	13.8	13.7	13.7	13.7
7.8	67.4/67.4	5.7	7.6	7.6	7.6	7.4	7.4	7.5	7.4	7.3	7.3	7.3
1.4	67.7/67.8	5.5	1.4	1.2	1.2	1.2	1.2	1.2	1.1	1.1	1.1	1.1
	/											
15.4	37.4/34.6	7.5	16.2	16.2	16.6	16.5	16.6	16.3	16.3	16.2	16.2	15.9
7.0	37.8/39.2	7.5	7.1	7.1	7.1	7.0	7.1	7.1	7.0	7.0	7.0	7.0
1.4	38.6/39.8	7.2	1.4	1.3	1.4	1.3	1.3	1.3	1.3	1.1	1.2	1.2
	/											
15.8	39.0/39.8	5.8	16.0	15.6	15.7	15.4	15.4	15.7	15.6	15.5	15.4	15.3
8.6	38.4/39.2	5.5	8.2	8.1	8.1	8.1	8.1	8.0	8.0	8.2	8.2	8.1
1.6	39.2/39.8	5.6	1.8	2.0	2.1	2.0	2.0	2.0	1.7	1.8	1.7	1.7
	/											
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

DATE :

4/9/87

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine WQAU-P Unit mg/l
 Sheet 2 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
16.8	86.2/85.6	7.3	15.9	16.2	15.9	15.9	15.8	15.2	15.6	15.6	15.9	15.4
7.8	86.6/86.4	7.5	7.6	7.6	7.6	7.7	7.7	7.6	7.5	7.5	7.4	7.4
1.2	89.2/89.0	7.5	1.0	1.0	1.1	1.1	1.1	1.1	1.2	1.1	1.1	1.1
	/											
18.2	87.3/87.0	5.5	17.9	17.9	18.0	18.1	17.8	17.9	17.7	17.7	17.7	17.6
8.0	87.0/87.0	6.1	8.1	8.1	8.1	8.0	8.0	8.0	7.9	7.9	7.8	7.7
1.0	88.4/88.0	5.7	1.0	1.2	1.1	1.1	1.1	1.3	1.1	1.1	0.9	0.8
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

DATE : 4/9/87

SIGNATURE : 

Monitored Parameter
Sheet of

Monitored Parameter
Sheet of


WQAU-P Unit

6

[illegible]

COMMENTS / OBSERVATIONS :

DATE : 4/9/87

SIGNATURE : 

Monitored Parameter Temp A15 WQAU-P Unit 3
Sheet of

[illegible]

DATE : 4/10/87

SIGNATURE : 

VQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 2

chlorine

VQAU-P Unit

3

Value of Standard	Temperature of Standard (VQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
20.0	64	6.8										
19.6	67/64.4	6.8	18.8	18.9	18.4	18.4	17.5	17.4	16.6	16.2	15.8	15.0
10.0	68/67.7	6.8	(8.0)	(6.7)	(8.9)	9.0	(8.7)	9.0	(8.9)	9.0	9.2	9.0
1.0	71/71.2	7.0	1.7	1.7	1.6	1.7	1.5	1.4	1.5	1.4	1.3	1.7
	1											
15.4	66	5.6	16.6	16.4	17.1	17.2	17.4	17.9	18.0	18.1	18.2	18.2
15.4	68/67.2	5.6	14.4	14.9	14.8	14.7	14.5	(14.7)	(14.1)	(14.1)	(14.4)	(14.7)
6.6	66/66.8	6.0	(4.8)	(4.8)	(4.4)	(4.9)	(4.8)	(4.7)	(4.4)	(4.7)	(4.8)	(4.7)
1.0	67/67.4	5.0	.6	.7	.8	.7	.6	.7	.7	.7	.6	.7
	1											
14.2	88/88.2	7.3	14.1	14.7	14.1	14.2	14.3	14.1	14.0	14.1	14.1	14.0
5.0	86/87.1	7.2	5.7	5.8	5.4	5.7	5.8	5.7	5.7	5.8	5.8	5.8
1.4	89/89.4	7.4	.8	.9	1.0	1.1	1.1	.8	.7	.8	.7	.6
	1											
17.4	88/89.0	5.7	(18.7)	(18.7)	16.4	17.9	17.5	17.7	16.9	16.8	16.9	16.7
8.2	90/91.0	5.6	(9.4)	9.1	9.0	8.8	8.6	8.7	8.8	8.6	8.4	8.3
1.1	91/91.4	5.2	1.0	1.1	1.0	0.9	0.8	0.4	0.5	0.5	0.4	0.6
	1											
	1											
	1											

COMMENTS / OBSERVATIONS :

DATE : 4/10/87

SIGNATURE : 

WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine WQAU-P Unit 3
 Sheet 2 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
13.8	38/38.2	7.4	14.1	14.8	14.9	14.4	14.7	14.2	14.1	14.1	14.0	13.8
9.0	39/38.4	7.5	10.0	10.1	10.0	9.7	9.6	9.5	9.5	9.4	9.4	9.7
1.4	37/36.8	7.2	1.7	1.6	0.8	0.9	1.2	1.3	1.2	1.1	1.2	1.0
	/											
17.4	37/35.8	5.6	19.2	19.0	17.9	18.4	18.2	18.0	17.7	17.8	17.9	17.6
7.3	39/38.2	5.3	7.9	7.4	7.6	7.7	7.8	7.9	8.2	8.0	7.7	7.4
1.7	40/39.0	5.2	1.6	1.4	1.3	1.3	1.3	1.2	1.4	1.2	1.1	1.2
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

DATE : 4/10/87

SIGNATURE : *[Signature]*

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 2

Chlorine


WQAU-P Unit

1

Value of Standard	Temperature of Standard (WQAU-P/ Actual	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
15.2	41/40.5	8	14.8	(14.8)	14.3	15.0	14.5	14.5	14.5	14.3	14.3	14.6
6.4	42/41.2	7.7	9.1	6.5	6.7	6.8	6.8	6.9	7.1	7.2	7.3	7.4
1.0	42/41.8	7.1	(3.0)	(3.1)	(3.0)	(3.1)	(2.8)	(2.7)	(2.7)	(2.8)	(2.9)	(2.6)
1.2	42/41.0	5.4	1.6	1.7	1.7	1.8	1.7	1.8	1.7	1.8	1.7	1.6
7.0	41/41.2	5.0	6.4	7.3	7.7	7.4	7.8	7.9	7.3	7.4	7.4	7.2
14.0	41/42	5.2	14.9	(15.1)	15.0	15.0	14.8	14.9	14.7	14.8	14.4	14.4
10.0	71/70.8	7.5	(11.4)	(11.5)	(11.2)	(11.1)	(11.3)	(11.3)	(11.4)	11.0	(11.7)	(11.7)
6.0	72/70.8	7.4	5.2	5.4	5.6	5.7	5.5	5.2	5.5	5.2	5.5	5.6
1.2	70/66.8	7.2	0.7	0.7	0.6	0.7	0.8	0.8	0.7	0.6	0.7	0.6
1.2	70/66.8	5.3	0.8	0.7	0.7	0.6	0.8	0.8	0.7	0.7	0.8	0.8
6.4	71/69.8	5.5	7.1	7.0	6.4	6.2	6.1	6.0	6.0	6.1	6.2	6.3
14.2	71/70.4	5.4	(16.0)	(16.0)	(15.8)	14.9	(15.3)	14.4	15.1	14.4	14.8	14.6
17.8	96/192	7.5	(20.1)	(21.2)	(19.4)	17.8	18.4	17.9	18.2	(1.2)	18.6	18.2
7.6	91/70.0	7.3	6.9	7.1	7.2	7.4	7.5	7.5	7.6	7.9	7.8	7.9
0.8	96/95.4	7.0	.7	.7	.8	1.3	1.0	1.1	.7	.5	.4	.4
0.8	96/94.9	5.2	0.1	0.1	0.1	0.1	0.5	0.4	0.6	0.4	0.2	0.1
8.4	92/93.1	5.4	8.2	8.4	8.6	8.5	8.7	9.1	8.8	8.7	8.8	8.6
16.6	90/91.2	5.9	(20.7)	(20.4)	(20.6)	(20.3)	(20.0)	(19.9)	(19.8)	(20.0)	(20.0)	(19.9)
	90/91.4	5.2										
	1											

COMMENTS / OBSERVATIONS :

DATE : 4/10/87

SIGNATURE : 

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 1

PH

WQAU-P Unit

S/N 007


PRABE 004

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										WQAU-P/ACT
			1	2	3	4	5	6	7	8	9	10	
4	41.0		3.5	3.6	3.7	3.7	3.7	3.7	3.7	3.7	3.7	3.7	41.0/39.4
7	37.4		7.0	7.0	7.1	7.1	7.1	7.1	7.1	7.1	7.1	7.1	37.4/38.1
10	37.4		9.7	9.7	9.8	9.8	9.9	9.9	9.9	9.9	10.0	10.0	37.4/38.1
4	66.2		3.7	3.7	3.7	3.6	3.7	3.7	3.6	3.7	3.6	3.7	66.2/66.4
7	66.2		7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	66.2/66.2
10	66.2		9.8	9.8	9.8	9.8	9.8	9.8	9.8	9.8	9.8	9.8	66.2/66.6
4	98.6		4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2	98.6/97.5
7	100.8		7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	98.6/98.6
10	98.6		9.8	9.8	9.8	9.8	9.8	9.7	9.8	9.8	9.8	9.8	98.6/97.5
4	118.4		4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2	118.4/115.4
7	116.6		7.0	7.1	7.1	7.0	7.0	7.0	7.0	7.0	7.1	7.0	114.8/114.3
10	118.4		9.6	9.7	9.7	9.7	9.7	9.6	9.6	9.7	9.7	9.6	118.4/116.4

COMMENTS / OBSERVATIONS :

DATE : 4/28/87

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 1

PH

WQAU-P Unit

S/N 005

PROBE 003

Value of Standard	Temperature of Standard (WQAU-P/ Actual	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
4	42.3		3.9	3.9	3.9	3.9	3.9	3.9	3.9	3.9	3.9	3.9
7	41.0		7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0
10	39.2		10.3	10.3	10.4	10.4	10.4	10.4	10.4	10.4	10.4	10.4
4	64.3		4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0
7	64.3		7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0
10	64.3		10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
4	98.6		4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1
7	95.8		7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0
10	98.6		10.0	10.0	10.0	10.0	9.9	10.0	10.0	10.0	10.0	10.0
4	114.8		4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1	4.1
7	115.6		7.1	7.1	7.1	7.1	7.1	7.1	7.1	7.1	7.1	7.1
10	116.6		10.0	10.0	10.0	9.9	9.9	9.9	10.0	10.0	9.9	9.9

COMMENTS / OBSERVATIONS :

DATE : 4/28/87

SIGNATURE :

[Signature]

WQAU-1 TEST DATA SHEET

Monitored Parameter TDS WQAU-P Unit 007
 Sheet 1 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
50	37.4		56	56	56	56	56	56	56	57	58	60	37.4/37.6
100	37.4		86	85	85	85	86	84	85	84	84	84	37.4/37.2
500	37.4		403	404	404	404	403	404	404	404	404	403	37.4/36.3
1500	37.4		1351	1354	1356	1356	1351	1354	1351	1351	1356	1351	37.4/36.9
3000	37.2		2795	2795	2795	2790	2786	2790	2786	2786	2786	2781	37.4/36.3
30,000	37.4		29551	29551	29551	29551	29551	29551	29551	29551	29551	29551	37.4/36.8
50,000	37.4		47209	47209	47209	47263	47263	47263	47263	47263	47263	47209	37.4/36.9
50	66.2		69	73	58	59	59	58	59	59	60	60	66.2/66.7
100	64.3		85	90	85	85	86	87	85	86	85	86	64.3/66.0
500	64.3		419	417	417	417	419	419	419	419	419	419	65.3/66.0
1500	64.3		1437	1443	1448	1443	1443	1443	1443	1443	1443	1440	64.3/65.8
3000	64.3		2973	2973	2973	2973	2973	2973	2973	2973	2973	2973	64.3/65.6
30,000	64.3		31417	31417	31417	31417	31417	31417	31417	31417	31417	31417	64.3/66.0
50,000	66.2		47667	47667	47667	47667	47667	47667	47667	47667	47667	47667	66.2/66.0
* 30,000	41.0		32327	32327	32376	32425	32425	32229	32229	32229	32229	32278	42.4/44.8
* 50,000	42.3		51189	50587	50387	50236	50136	50086	49986	49986	49986	50036	
* 30,000	68.6		32087	32087	32087	32087	32087	32087	32087	32087	32087	32087	67.2/69.2
* 50,000													


COMMENTS / OBSERVATIONS :

* NEW TEMP. TAKEN

XX REVALIDATED BY/ NEW STANDARDS

DATE : 4/21/97

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter TDS
Sheet 1 of 2

WQAU-P Unit 007

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
50	100.4	1	31	31	81	39	57	39	34	35	39	34	96.7/97.2
100	100.4	1	77	(73)	77	(67)	(67)	(67)	(67)	(67)	(67)	(66)	94.6/93.6
500	102.2	1	373	373	373	372	373	371	373	373	369	368	100.4/100.9
1500	102.2	1	1311	1311	1311	1307	1308	1311	1307	1311	1303	1307	99.5/98.7
3000	102.2	1	2802	2798	2798	2798	2793	2797	2793	2789	2785*	2820	100.4/100.4
30,000	102.2	1	28810	28810	28810	28810	28810	28810	28810	28835	28810	28835	102.2/102.0
50,000	102.2	1	47895	47838	47838	47838	47838	47838	47781	47810	47741*	47908	100.4/100.2
50	120.2	1	36	36	36	37	36	36	36*	36	36	36	114.8/114.4
100	122.2	1	82	82	80*	78	78	(73)	(65)	(72)	(60)	(65)	114.8/114.6
500	122.0	1	347	322	365	371	372	372	369	363*	366	364	120.2/119.5
1500	122.0	1	1259	1317	1310	1306*	1319	1311	1304*	1325	1317	1312	118.4/118.2
3000	116.6	1	2900	2884	2864*	2884	2866	2816*	2864	2848*	2820	2863	111.2/110.5
30000	120.2	1	24968	29012	28968	28951	28947	2884*	2900	28922	28834	28790	117.5/117.4
50,000	123.8	1	47894	47741*	4754*	(4744)	(47326)	47668	4754	4732*	47516	47336	108.4/117.9
30,000	98.6	1	30101	30208	30181	30129	30129*	31103	31021	30940	30833*	31228	93.2/92.7
50,000	105.8	1	49089	48977	48865	48850*	48753	48640	48584	48528	48472	48416	104.0/103.1
30,000	118.4	1	29805	29760	29760	29716	29672	29605	29539	29495	29448	2937	113.0/112.8
50,000	118.4	1	48758	48731	48703	48649	48594	48536	48481	48411	48315	48205	113.4/113.0

COMMENTS / OBSERVATIONS :

* NEW TEMP TAKEN

** REVALIDATED w/ NEW STANDARDS

DATE :

SIGNATURE :

4/12/87

WQAU-P TEST DATA SHEET

Monitored Parameter TDS WQAU-P Unit 005
 Sheet 1 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
50	39.2'		54	54	54	54	54	54	54	54	54	54	39.2/31.9
100	39.2'		85	85	85	84	85	84	84	84	84	84	39.2/36.8
500	37.4'		455	455	455	455	455	455	455	454	455	454	37.4/36.3
1500	39.2'		1325	1321	1321	1324	1321	1325	1325	1321	1317	1325	37.4/36.3
3000	37.4'		2833	2833	2833	2833	2828	2833	2824	2828	2833	2824	37.4/36.3
30000	37.4'		28809	28809	28809	28809	28809	28809	28809	28809	28809	28809	37.4/36.3
50,000	37.4'		46061	46180	46180	46180	46180	46180	46180	46125	46125	46180	37.4/37.0
50	66.2'		60	60	60	60	60	61	61	61	61	61	66.2/66.2
100	64.3'		86	86	87	87	87	87	87	88	87	88	64.3/66.0
500	64.3'		452	451	450	452	452	452	452	451	452	451	64.3/65.1
1500	64.3'		1456	1456	1456	1456	1456	1456	1456	1456	1456	1456	64.3/64.8
3000	64.3'		2986	2993	2993	2997	2996	2996	2996	2993	2999	2999	64.3/64.8
30,000	64.3'		30624	30587	30587	30587	30587	30587	30587	30662	30587	30587	64.3/65.1
50,000	64.3'		47073	47073	47073	47073	47073	47073	47073	47073	47073	47073	64.3/64.8
* 30,000	42.8'		32387	32113	32161	32161	32161	32161	32056	32056	32056	32164	44.6/44.5
* 50,000	44.6'		49765	49780	49667	49570	49521	49570	48944	48937	48926	49043	46.4/47.3
* 30,000	68.0'		31496	32376	32448	32301	32159	32159	32159	32159	32087	32087	68.0/69.9
* 50,000	66.2'		50576	50729	50729	50729	50805	50805	50805	50643	50882	50643	66.2/68.4


COMMENTS / OBSERVATIONS :

* NEW TEMP TAKEN

* REVALIDATED w/ NEW STANDARDS

DATE : 4/24/87

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 2 of 2

TDS

WQAU-P Unit

005

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
50	95.0		44	41	43	43	43	43	43	43	43	42	95.0/94.8
100	91.3		80	79	81	80	79	79	79	80	80	79	91.2/91.8
500	98.6		933	933	930	933	933	933	933	930	932	932	96.7/95.8
1500	98.6		1406	1402	1403	1398	1398	1403	1401	1398	1394	1394	97.7/97.4
3,000	98.6		2889	2894	2894	2894	2898	2902	2897	2898	2898	2898	98.6/97.9
3,000	100.4		2863	2863	2863	2863	2863	2863	2863	2863	2863	2863	98.6/97.9
30,000	100.4		28637	28637	28637	28637	28663	28688	28668	28668	28668	28668	98.6/98.6
50,000	100.4		40142	40142	40118*	40118	40093*	40751	40676	40676	40626	40626	98.6/97.7
50	22.0		61	62	61	60	49	42*	39	38	36*	37	118.4/119.4
100	125.0		77	75	77*	77	77	77	77	76	76	76	120.2/119.9
500	125.6		429	429	429	429*	435	433	434	432	432	432	122.0/121.6
1500	123.8		1384	1380	1380*	1388	1386	1384	1381*	1395	1391	1387	120.2/120.1
3,000	123.8		3027	3027	3027	3023	3016	3004	3001	2997	2988*	3098	118.4/117.5
30,000	125.6		27554	27533	27513*	2795	2798	27789	27715	28069	28071	28003	120.2/120.0
50,000	123.8		45252	45174	45122*	45565	45340	45230	45150*	45150	45096	45043	113.0/112.7
* 30,000	100.4		29664	29767	29767	29716	29614	29664	29613	29552	29510	29485	95.0/94.7
* 50,000	108		49763	49763	49763	49763	49651	49651	49651	49545	49515	49539	106/105
* 30,000	120.2		29099	29143	29143	29143	29099	29056	29012	28970*	29317	29317	116.6/115.8
* 50,000	115.2		47893	47892	47856	47856	47853	47863	47800	47863	47910	47910	108.3/110

COMMENTS / OBSERVATIONS :

* NEW TEMP TA RECAL

* RECALCULATED w/ NEW STANDARDS

DATE : 4/24/87

SIGNATURE :

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 1

TURBIDITY

WQAU-P Unit 057

Value of Standard	Temperature of Standard (WQAU-P/ Actual	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
147	64.3'		143	138	144	142	143	140	142	142	143	146
100.7	64.3'		97	98	99	100	99	99	100	99	97	99
53.7	64.3'		52	53	53	52	55	53	55	52	57	52
11.0	62.6'		10	10	10	10	11	10	16	11	12	11
3.1	64.3'		0	1	2	3	2	4	3	3	3	4
150.0	37.4'		147	144	146	144	150	148	148	150	148	148
100.5	37.4'		99	99	100	99	99	100	101	98	99	99
53.9	37.4'		54	56	54	55	54	59	54	55	56	54
11.4	37.4'		10	8	9	10	10	11	12	11	12	9
3.6	37.4'		3	4	3	2	3	1	3	2	3	2
158.2	93.2'		149	148	155	154	156	153	154	155	154	156
104.9	95.8'		112	111	106	(116)	111	111	112	102	105	117
54.6	95.0'		53	60	54	54	53	(67)	62	55	57	(67)
13.4	95.0'		18	17	(19)	18	17	(21)	(19)	18	(21)	(20)
3.8	98.0'		3	(13)	9	(12)	9	(10)	(11)	7	2	(11)
129.9	122.0'		(141)	127	130	128	131	130	131	127	128	127
108.1	119.4'		115	109	108	112	(91)	104	103	108	105	104
44.3	117.6'		39	(37)	46	(38)	(38)	(50)	48	47	44	(5-6)
11.2	118.2'		7	14	7	12	12	(14)	15	(3)	6	9
3.7	118.4'		9	6	3	2	2	4	1	5	0	6

COMMENTS / OBSERVATIONS :

DATE : 4/30/87

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter TURBIDITY
Sheet 1 of 1


WQAU-P Unit 005

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
148.3	64.3'		150	147	147	147	154	145	147	148	150	145	64.3/64.7
100.2	66.2'		98	105	105	100	99	100	101	100	99	102	64.3/64.5
54.0	64.3'		55	66	55	56	55	55	56	55	55	54	64.3/65.5
10.5	64.3'		11	11	10	11	10	10	10	12	13	4	64.3/65.3
3.1	62.4'		4	2	3	2	3	3	3	2	4	4	62.6/62.9
149.9	37.4'		152	151	150	152	154	152	148	150	151	150	41.0/42.6
10.4	37.4'		105	106	107	106	106	107	107	107	102	102	39.2/40.5
53.8	37.4'		51	54	60	58	54	53	54	55	54	55	39.2/39.4
10.9	37.4'		10	10	9	10	9	10	9	8	9	13	37.4/36.8
3.2	37.4'		3	3	3	4	4	3	4	2	4	2	37.4/37.1
149.3	95.0'		155	154	152	152	150	151	155	152	155	158	87.8/86.8
94.5	95.8'		96	92	101	96	97	98	97	101	99	101	86.0/85.8
58.6	95.0'		62	61	58	58	60	59	60	59	60	63	87.8/93.0
11.5	95.8'		10	10	10	11	10	11	14	11	13	10	82.3/82.7
3.9	97.6'		4	(16)	4	9	6	6	5	7	6	7	82.3/81.7
169.7	118.2'		165	176	164	186	176	167	170	175	172	175	90.7/92
94.3	117.6'		92	87	87	84	96	100	87	89	87	89	105.8/106.2
46.1	117.6'		42	42	(96)	41	41	(56)	49	49	45	46	111.2/112.1
11.1	118.2'		(2)	6	(3)	9	9	(5)	10	12	10	11	105.8/110.2
3.7	118.2'		0	5	0	1	0	4	1	4	3	2	109.4/110.7

COMMENTS / OBSERVATIONS :

DATE : 4/30/87

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter, TEMP AIR WQAU-P Unit 007
Sheet 1 of 1

[illegible]

COMMENTS / OBSERVATIONS :

DATE : 5/1/87

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter AIR TEMP
Sheet 1 of 1

WQAU-P Unit

[illegible]

COMMENTS / OBSERVATIONS :

DATE : 5/1/87

SIGNATURE :

E : 

WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine WQAU-P Unit 5
 Sheet of

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
13.4	68 / 69.1	7.4	13.3	13.3	13.4	13.4	13.4	13.3	13.3	13.3	13.1	13.1
10.7	67.7 / 68.0	7.3	9.7	9.9	10.1	10.2	10.4	10.4	10.3	10.5	10.8	10.4
1.5	72.5 / 72.1	7.2	1.7	1.6	1.5	1.5	1.6	1.7	1.7	1.6	1.7	1.6
	/											
14	96 / 95.4	7.3	14.5	14.2	13.8	13.6	13.5	13.2	12.0	12.7	12.5	12.3
	/											
16.2	37.8 / 38.0	7.4	17.1	17.1	17.0	16.8	16.9	12.4	15.2	16.1	17.1	17.0
8.1	38 / 38.2	7.2	9.0	9.0	8.6	8.7	8.4	8.5	8.5	8.4	8.3	8.1
2.1	39.1 / 38.8	7.1	2.1	2.0	2.0	2.0	1.8	1.7	1.8	1.6	1.6	1.5
	/											
7.1	96 / 95.8	7.3	9.0	6.9	6.9	6.7	6.6	6.8	6.4	6.2	6.8	6.0
1.2	95.2 / 95.4	7.2	1.3	1.2	1.2	1.1	1.1	1.0	1.1	0.9	0.8	0.7
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

* High Temp Chlorine driven off to part.

DATE : 5/1/67

SIGNATURE : *SSM*

WQAU-P TEST DATA SHEET

Monitored Parameter _____ WQAU-P Unit _____
Sheet _____ of _____

[illegible]

COMMENTS / OBSERVATIONS :

DATE :

SIGNATURE :

WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine
Sheet of

WQAU-P Unit 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
15.8	66.1/67.1	7.2	15.2	15.2	15.2	15.0	15.1	15.1	15.2	15.0	15.0	15.0	
10.1	65.6/67	7.1	9.8	10.1	10.0	10.3	10.2	9.9	9.9	9.8	9.8	9.7	
1.8	71.7/72.1	6.9	0.9	1.5	1.6	1.7	1.2	0.9	1.2	1.2	1.2	1.1	
	/												
12.0	101/102	7.1	11.9	10.4	10.6	10.2	10.2	10.3	10.1	10.3	9.6	9.8	
	100/100	7.1											
14.4	36.2/36.8	7.2	15.1	15.0	15.2	14.9	14.8	14.7	14.7	14.6	14.5	14.3	
7.2	37.1/37.4	7.1	8.0	8.0	8.0	7.3	7.9	6.7	6.5	6.4	6.3	6.1	
1.5	38.0/38.8	7.1	1.8	1.7	1.7	1.6	1.5	1.7	1.3	1.1	1.2	0.8	
	/												
15.2	71/70.6	5.3	14.8	14.9	15.3	15.1	14.6	14.7	14.4	14.3	14.1	14.0	
8.0	71/71.2	5.2	8.2	8.1	7.9	7.9	7.8	7.7	7.7	7.6	7.4	8.0	
	/												
	43.3/44.1	5.8											
	/												
	/												
	/												
	/												

COMMENTS / OBSERVATIONS : * Temp to hot chlorine coming off to quickly

Water + Chlorine + HCl to lower pH

pH 5.4 T- 60°F DPD- 4.4 WQM- 3.6 mg/L

ADD Chlorine

4.3 60 DPD- WQM 6.1

ADD Chlorine:

DATE : 5/1/87

SIGNATURE : *JSR*

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet ofChlorine

WQAU-P Unit


7

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
* 8.6	65.3/65.6	5.7	8.2	8.2	8.2	8.1	8.0	8.0	7.8	7.8	7.8	7.7
	65.3/65.7	6.0										
<hr/>												
* 13.6	59.6/60.1	5.2	(14.4)	14.1	14.0	14.1	14.2	14.2	13.7	13.6	13.8	13.8
7.6	58.2/58.5	5.3	8.1	7.7	7.9	8.4	8.3	8.1	8.0	7.9	8.0	8.1
1.1	55.4/56.0	5.5	1.1	0.9	1.0	0.9	0.8	0.7	0.7	0.8	0.7	0.6
<hr/>												
13.4	32.4/38.3	5.1	12.6	12.5	12.4	12.8	12.6	(12.1)	(12.2)	(12.1)	(12.3)	(12.1)
4.0	38.5/39.0	5.1	4.8	4.7	4.6	4.6	4.6	4.6	4.6	4.7	4.6	4.5
0.8	37.7/38.1	5.2	1.2	1.2	1.3	1.4	1.3	1.3	1.2	1.2	1.1	1.2
<hr/>												
13.6	46.0/45.1	5.3	(15.0)	(15.2)	(15.1)	(14.8)	14.5	14.3	14.4	14.4	14.2	14.7
5.6	45.7/45.4	5.4	5.6	5.5	5.4	5.6	5.3	5.4	5.2	5.0	4.7	(4.5)
0.9	48.0/47.7	6.1	.6	.6	.4	.5	.6	.5	.4	.4	.3	.2
<hr/>												
13.5	46.0/45.0	7.2	13.4	13.4	13.7	14.0	13.7	13.4	13.2	13.0	12.9	12.7
7.0	44.3/46.0	7.1	6.5	6.6	6.5	6.3	6.3	6.3	6.0	(5.7)	(5.4)	(5.0)
0.4	46.9/	7.1	0.4	0.3	0.3	0.3	0.2	0.1	0.2	0.1	0.1	0.1
<hr/>												

COMMENTS / OBSERVATIONS : * pH adjusted with HCl not buffer
 * Use buffer 4.0

DATE : 5/1/87

SIGNATURE



WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine WQAU-P Unit 5
 Sheet _____ of _____

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
12.4	62.7/63.0	5.2	11.7	12.1	12.1	12.0	12.0	12.1	12.0	11.8	11.8	11.9
4.6	60.6/60.8	5.5	4.1	4.2	4.4	4.3	4.3	4.4	4.3	4.3	4.3	4.3
2.3	60.7/60.9	5.0	1.4	1.4	1.4	1.5	1.4	1.4	1.4	1.5	1.4	1.4
	/											
15.0	39.3/39.4	4.9	15.2	15.3	15.2	15.7	15.3	15.2	15.6	15.5	15.5	15.5
6.4	39.2/39.4	4.9	7.0	6.7	6.8	6.9	7.0	6.9	6.8	6.9	6.8	6.7
0.6	38.9/39.3	5.3	1.1	1.1	1.1	1.1	1.1	1.0	1.0	1.0	1.1	1.0
	/											
12.2	96.6/95.9	5.2	12.7	12.4	12.1	11.1	11.9	11.8	11.6	11.4	11.1	11.2
5.0	94.8/95.1	5.6	5.2	5.3	5.1	5.0	5.1	4.9	4.7	4.8	4.7	4.4
0.8	95.1/95.0	6.1	0.8	0.7	0.9	0.6	0.7	0.9	0.8	0.8	0.8	0.7
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

DATE : 5/1/07

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter PH WQAU-P Unit 004 HEAD #006
 Sheet 1 of 1

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
4	33.0'		3.6	3.6	3.6	3.6	3.6	3.7	3.7	3.7	3.7	3.7	33.2/33.8
7	33.6'		6.8	6.9	6.8	6.9	6.8	6.8	6.8	6.8	6.8	6.8	32.8/34.5
10	32.9'		9.5	9.6	9.6	9.6	9.6	9.6	9.6	9.6	9.6	9.6	33.4/36.5
	'												
4	68.7'		4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	68.7/68.4
7	68.9'		7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	7.0	68.9/69.1
10	68.7'		10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	69.0/68.4
	'												
4	102.5'		4.0	4.0	4.0	4.0	3.9	4.0	3.9	3.9	3.9	3.9	102.7/102.6
7	94.7'		6.9	6.9	6.9	6.9	6.9	6.9	6.9	6.9	6.9	6.9	98.6/97.2
10	104.5'		9.8	9.8	9.8	9.8	9.8	9.8	9.8	9.8	9.8	9.8	103.0/102.2
	'												
4	111.2'		4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	111.2/110.1
7	112.4'		6.9	6.9	6.9	6.9	6.9	6.9	6.9	6.9	6.9	6.9	112.1/110.5
10	111.0'		9.8	9.8	9.8	9.8	9.8	9.8	9.7	9.7	9.7	9.7	109.7/108.5
	'												
	'												
	'												
	'												
	'												
	'												

COMMENTS / OBSERVATIONS :

DATE : 6/1/87

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter TDS WQAU-P Unit 004 1+GAD 006
 Sheet 1 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
50	33.0 '		61	61	62	61	62	62	62	62	62	62	33.9/34.2
100	33.8 '		100	100	100	100	100	100	100	100	100	100	33.8/34.7
500	33.6 '		504	505	503	505	506	504	506	506	505	506	33.9/34.1
1500	33.6 '		1344	1397	1397	1397	1405	1397	1397	1397	1397	1397	33.6/33.4
3000	33.8 '		2898	2898	2898	2887	2887	2887	2887	2887	2887	2887	33.6/33.4
30000	33.6 '		31281	31281	31281	31394	31281	31394	31394	31394	31394	31394	33.4/33.4
50000	35.4 '		49667	49555	49667	49667	49667	49667	49667	49667	49667	49667	35.0/34.6
	'												
	'												
50	66.3'		36 34	34 30	34 30	34 30	50	50	50	50	50	50	67.8/68.5
100	67.4 '		86	86	88	89	88	88	88	88	88	88	68.5/68.4
500	68.5 '		468	470	471	471	471	470	471	469	471	469	68.1/68.4
1500	68.7 '		1391	1391	1393	1391	1391	1391	1391	1391	1391	1391	68.7/69.3
3000	68.9 '		2900	2900	2900	2900	2900	2900	2900	2900	2900	2893	68.1/69.1
30000	68.5 '		31570	31570	31642	31642	31583	31570	31575	31606	31570	31570	68.5/68.7
50000	66.9 '		51219	51256	51256	51256	51329	51329	51329	51329	51329	51329	68.8/68.5
	'												
	'												
	'												
	'												

COMMENTS / OBSERVATIONS :

50 C 68.3 FIRST 4 READINGS C WRONG TEMP

DATE : 6/2/87

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter TRD WQAU-P Unit 004 HEAD 006
 Sheet 2 of 2

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement										
			1	2	3	4	5	6	7	8	9	10	
50	104.0'		60	64	68*	69	71	71	71*	62	60	58	98.9/98.1
100	104.5'		48	88	87	86*	87	88	87	87	87	87	100.2/100.6
500	106.0'		463	462	462	460*	467	465	465	465	463	461	102.0/102.2
1,500	106.5'		1364	1364	1360	1360	1355*	1375	1370	1371	1366*	1377	102.4/102.6
3,000	107.2'		2861	2861	2861	2857	2853	2848	2842*	2885	2877	2873	104.6/103.8
30,000	106.7'		29825	29873	29873	29870	29849	29825	29825	29776	29721	29727	105.9/104.5
50,000	105.3'		50222	50166	50110	50110	50110	50053	49997*	50402	50345	50285	102.5/102.4
	/												
	/												
50	112.1'		52	52	52	52	52	52	52	52	52	52	107.2/107.1
100	112.0'		110	110	115	105	110	110	108	106	106	105	116.7/116.5
500	117.3'		516	515	515	515	514	510	509	506	502	499	112.1/111.9
1,500	114.8'		1399	1397	1397	1399	1395	1391	1390*	1411	1407	1403	111.3/111.2
3,000	118.4'		2843	2890	2889	2885	2875	2871*	2921	2911	2906*	2929	114.6/114.6
30,000	120.0'		29099	29186	29186	29186	29186	29186	29186	29143	29099	29099	118.0/117.5
50,000	118.2'		49372	49425	49425	49425	49425	49372	49372	49266	49213	49160	115.5/114.9
	/												
	/												
	/												
	/												

COMMENTS / OBSERVATIONS :

*NO TEMP TAKEN

DATE : 6/3/87

SIGNATURE :



WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet 1 of 1

TURBIDITY

WQAU-P Unit 004 HETAD 006

Value of Standard	Temperature of Standard (WQAU-P/ Actual	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
155.9	35.9'	0	155	156	158	159	156	160	159	155	160	160
105.5	35.2'	0	110	110	107	109	107	107	107	107	107	107
56.2	36.0'	0	60	58	61	66	59	60	61	60	58	59
16.9	34.4'	0	12	11	11	12	10	14	12	10	11	10
4.0	35.1'	0	4	3	4	5	4	4	4	4	3	3
152.4	68.7'	0	155	155	155	155	155	150	158	150	161	161
95.9	67.6'	0	102	95	99	101	98	99	101	95	95	97
54.2	67.8'	0	51	52	54	57	57	57	57	52	54	57
16.4	67.8'	0	9	14	11	11	8	11	10	11	10	11
3.7	67.6'	0	1	3	2	3	3	3	6	4	3	1
148.0	104.0'	1	145	140	153	143	146	139	165	153	147	144
102.5	106.5'	4	89	110	98	108	108	98	120	115	115	119
53.4	102.0'	1	50	54	56	50	51	43	63	59	52	65
11.5	101.3'	1	7	14	14	14	12	10	21	11	12	7
3.9	104.6'	1	1	0	1	1	0	0	12	7	0	1
144.2	119.1'	4	149	158	118	146	138	146	162	161	152	142
99.0	120.9'	4	102	90	119	92	98	114	98	106	112	96
50.6	121.4'	2	61	54	43	40	33	46	57	52	52	57
16.7	120.2'	3	4	3	9	15	8	9	8	8	10	4
4.1	126.1'	3	5	13	4	5	4	11	2	16	7	0

COMMENTS / OBSERVATIONS :

2/1200

* STERILE SAMPLE

1st FOUR READINGS 210NM 1063 OF NOT ENOUGH SOLID IN CONTAINER READINGS REDONE

DATE : 6/15/87

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter
Sheet of

Chlorine

WQAU-P Unit

4 hrs/6

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
13.6	66.4/62.0	5.6	14.4	14.6	14.8	14.5	14.4	14.2	14.1	14.1	14.1	14.0
2.0	60.8/61.0	5.7	8.7	8.1	8.1	8.0	7.8	7.6	7.6	7.6	7.5	7.6
1.2	61.0/66.4	5.5	1.1	1.1	1.1	1.1	1.0	1.0	1.0	1.0	1.0	1.0
/	/	/										
16.4	35.8/36.2	5.7	16.0	16.2	16.0	16.0	15.8	15.6	15.6	15.4	15.2	15.2
8.0	37.0/37.2	5.5	8.0	8.0	8.1	8.1	7.9	7.7	7.8	7.8	7.7	7.6
1.6	37.4/37.6	5.5	1.4	1.4	1.3	1.3	1.2	1.2	1.2	1.2	1.2	1.1
/	/	/										
15.2	88.2/88.4	5.8	15.8	15.8	15.8	15.6	15.4	15.1	15.1	15.0	14.7	13.8
7.6	87.0/87.2	5.6	7.8	7.7	7.7	7.6	7.4	7.2	7.1	7.1	7.0	6.0
1.0	88.4/88.8	5.4	1.2	1.2	1.1	1.1	1.1	0.8	0.9	0.7	0.7	0.7
/	/	/										
/	/	/										
/	/	/										
/	/	/										
/	/	/										
/	/	/										
/	/	/										
/	/	/										
/	/	/										
/	/	/										

COMMENTS / OBSERVATIONS :

DATE : 6/8/87

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Monitored Parameter Chlorine
Sheet 2 of 2

WQAU-P Unit 4 hrs/6

Value of Standard	Temperature of Standard (WQAU-P/ Actual)	pH of Standard*	Measurement									
			1	2	3	4	5	6	7	8	9	10
15.2	89.8/90.0	7.3	16.4	16.6	16.2	16.1	16.0	16.0	16.0	15.8	15.6	15.2
6.8	89.0/89.8	7.6	7.8	7.8	7.2	7.1	7.0	6.8	6.4	6.2	6.0	5.9
1.0	88.6/89.2	7.6	2.1	2.1	1.8	1.6	1.5	1.5	1.4	1.3	1.3	1.3
	/											
18.4	169.2/170.0	7.5	17.8	17.8	17.6	17.9	17.6	17.6	17.4	17.2	17.0	17.1
7.2	169.4/169.8	7.1	6.8	6.6	6.6	6.5	6.4	6.4	6.4	6.4	6.4	6.3
0.6	68.2/69.0	7.1	1.0	1.0	1.1	1.1	1.0	0.8	0.8	0.8	0.8	0.8
	/											
19.6	36.6/36.0	7.8	18.4	18.5	18.2	18.6	18.6	18.5	18.4	18.4	18.4	18.4
9.0	37.2/37.6	7.4	8.8	8.8	8.7	8.6	8.6	8.6	8.6	8.4	8.4	8.5
1.4	32.6/32.8	7.3	1.8	1.8	1.7	1.7	1.7	1.7	1.8	1.6	1.7	1.7
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											
	/											

COMMENTS / OBSERVATIONS :

DATE : 6/8/87

SIGNATURE :

[Signature]

WQAU-P TEST DATA SHEET

Air Temp WQAU-P Unit 4 per 16

WQAU-P Unit

COMMENTS / OBSERVATIONS :

* Actual Temp 142.2 °F when testing initiated

DATE : 6/8/87

SIGNATURE : 

WQAU-P TEST DATA SHEET

Monitored Parameter _____ WQAU-P Unit _____
Sheet _____ of _____

[illegible]

COMMENTS / OBSERVATIONS :

DATE :

SIGNATURE :